

# RouterBOARD 435G

## Copyright and Warranty Information

Copyright and Trademarks. Copyright MikroTik SIA. This manual contains information protected by copyright law. No part of it may be reproduced or transmitted in any form without prior written permission from the copyright holder. RouterBOARD, RouterOS, RouterBOOT and MikroTik are trademarks of MikroTik SIA. All trademarks and registered trademarks appearing in this manual are the property of their respective holders.


**Hardware.** MikroTik warrants all RouterBOARD series equipment for the term of fifteen (15) months from the shipping date to be free of defects in materials and workmanship under normal use and service, except in case of damage caused by mechanical, electrical or other accidental or intended damages caused by improper use or due to wind, rain, fire or other acts of nature.

To return failed units to MikroTik, you must perform the following RMA (Return Merchandise Authorization) procedure. Follow the instructions below to save time, efforts, avoid costs, and improve the speed of the RMA process.

1. If you have purchased your product from a MikroTik Reseller, please contact the Reseller company regarding all warranty and repair issues, the following instructions apply ONLY if you purchased your equipment directly from MikroTik in Latvia.
2. We do not offer repairs for products that are not covered by warranty. Exceptions can be made for RB1000, RB1100, RB1200.
3. Out-of-warranty devices and devices not covered by warranty sent to MikroTik will be returned to the sender at sender's cost.



RMA Instructions are located on our webpage here: <http://rma.mikrotik.com>

**Manual.** This manual is provided “as is” without a warranty of any kind, expressed or implied, including, but not limited to, the implied warranty of merchantability and fitness for a particular purpose. The manufacturer has made every effort to ensure the accuracy of the contents of this manual; however, it is possible that it may contain technical inaccuracies, typographical or other errors. No liability is assumed for any inaccuracy found in this publication, nor for direct or indirect, incidental, consequential or other damages that may result from such an inaccuracy, including, but not limited to, loss of data or profits. Please report any inaccuracies found to [support@mikrotik.com](mailto:support@mikrotik.com)



<b>COPYRIGHT AND WARRANTY INFORMATION .....</b>	<b>1</b>
<b>SYSTEM BOARD VIEW AND LAYOUT .....</b>	<b>3</b>
<b>SPECIFICATIONS.....</b>	<b>4</b>
<b>HARDWARE GUIDE .....</b>	<b>4</b>
MEMORY AND STORAGE DEVICES.....	4
<i>Memory</i> .....	4
<i>Storage Device</i> .....	4
INPUT/OUTPUT PORTS.....	4
<i>Ethernet ports</i> .....	4
<i>DB9 Serial Port</i> .....	5
COOLING FAN CONNECTORS.....	5
LEDS .....	5
<b>USER'S GUIDE .....</b>	<b>5</b>
ASSEMBLING THE HARDWARE .....	5
POWERING.....	5
BOOTING OPTIONS .....	5
<i>Onboard NAND Storage Device</i> .....	6
<i>Booting from network</i> .....	6
<i>Operating System Support</i> .....	6
SOFTWARE RESET.....	6
<b>ROUTERBOOT .....</b>	<b>6</b>
BOOT LOADER CONFIGURATION .....	6
BOOT LOADER UPGRADING .....	8
PRIMARY BOOT LOADER .....	8
<b>ROUTEROS FUNCTIONS .....</b>	<b>8</b>
HEALTH MONITOR .....	8
FIRMWARE INFORMATION .....	9
FIRMWARE SETTINGS .....	9
<b>APPENDIX .....</b>	<b>10</b>
CONNECTOR INDEX.....	10
BUTTON INDEX .....	10
ETHERNET CABLES.....	10
SERIAL NULL-MODEM (CONSOLE) CABLE WITH LOOPBACK .....	10

## System Board View and Layout



You can download the board dimensions and case design files (PDF and DXF) from [www.routerboard.com](http://www.routerboard.com)

# Specifications

	<b>RouterBOARD 435G</b>
CPU	AR7100 680MHz network processor
Memory	256MB onboard memory
Boot loader	RouterBOOT
Data storage	512MB onboard NAND memory chip
Ethernet	Three 10/100/1000 Mbit/s Ethernet ports supporting Auto-MDI/X
MiniPCI slot	Five miniPCI Type IIIA/IIIB ports with 3.3V power signaling
Expansion	2x USB 2.0 ports with 5V powering
Memory card slots	1x microSD
Serial port	DB9 RS232C asynchronous serial port
LEDs	Power and User LED
Beeper	+
Powering	<b>Power jack:</b> 8-30VDC <b>PoE:</b> 8-30V passive (803.af not supported)
Fans	Up to 4 fans (connectors provided, no fans included)
Dimensions	105 x 155 x 32 mm, 165g <i>(note: miniPCI slots on the bottom of the device extend 21mm deep, without miniPCI cards mounted)</i>
Temperature	Operational: -20°C to +65°C (-4°F to 149°F)
Humidity	Operational: up to 70% relative humidity (non-condensing)
Operating System	RouterOS v5, Level5 license

## Hardware Guide

### Memory and Storage Devices

#### Memory

The device has built in 256MB of onboard memory.

#### Storage Device

The device is equipped with one 512MB NAND nonvolatile memory chip. The device also has a microSD card slot, for extending the storage. This slot only works as a secondary storage device, you can't boot RouterOS from it.

### Input/Output Ports

#### Ethernet ports

There are three Gigabit ethernet ports.

All cables made to EIA/TIA 568A/B cable specifications will work correctly (see Connector Index for pinout). Note that this port supports automatic cross/straight cable correction (Auto MDI/X), so you can use either straight or cross-over cable for connecting to other network devices.

## DB9 Serial Port

The RS232C standard male DB9 asynchronous serial port may be used for initial configuration, or for attaching a modem or any other RS232 serial device. TxD (pin 3) of this port has -5V DC power when idle. Some signals are not connected, so this implementation may not be considered to support full hardware flow-control, so software flow-control (XON/XOFF) or none at all should be used.

## Cooling Fan Connectors

You can connect up to four fans, but only two of them will work at a time.

- JP101,JP104 are **3,3V**.
- JP102,JP103 is the same voltage as received by the power jack.

You can only use one pair of fans (ie. JP101 + JP104 or JP102 + JP103). It is recommended to use a 12V PSU for the RB device, and JP102,JP103 headers with 12V cooling fans.

## LEDs

Power LED is on when the board is powered. User LED may be programmed at user's option. It is lit by default when the board starts up, then it is turned off when the bootloader runs kernel.

## User's Guide

### Assembling the Hardware

In most cases you do not need to use any additional boot devices, as you can boot the RouterBOARD from the onboard NAND memory. You can also install one microSD card which you can use as an alternative boot device (not for RouterOS) or additional storage media;

### Powering

The board accepts powering from the power jack, or from the LAN1 Ethernet port:

1. Direct input power jack accepts 8-30V DC
2. LAN1 Ethernet port accepts 8-30 V DC input (at the board; higher voltage is needed to compensate for power loss on long cables – at least 18V suggested) from non-standard (passive) Power over Ethernet injectors. The board **does not** work with IEEE802.3af compliant 48V power injectors.

Max 3,3V load for miniPCI cards 19W ( 6A ) at 24V power with no active cooling.

Max 3,3V load for miniPCI cards 40W ( 12A ) at 24V power with active cooling.

### Booting options

First, RouterBOOT loader is started. It displays some useful information on the onboard RS232C asynchronous serial port, which is set to 115200bit/s, 8 data bits, 1 stop bit, no parity by default. Also supports hardware (RTS/CTS) flow control. The loader may be configured to boot the system from the onboard NAND module or from Ethernet network.

**By default, RouterOS is started. This is the operating system of all RouterBOARD routers. Please see detailed configuration guide here: <http://wiki.mikrotik.com/wiki/Category:Manual#list>**

## Onboard NAND Storage Device

The RouterBOARD may be started from the onboard NAND storage chip. As there is no partition table on the device, the boot loader assumes the first 4MiB form a YAFFS filesystem, and executes the file called “kernel” stored in the root directory on that partition. It is possible to partition the rest of the medium by patching the kernel source.

## Booting from network

Network boot works similarly to PXE or EtherBoot protocol, and allows you to the device from an executable image stored on a TFTP server. It uses BOOTP or DHCP (configurable in boot loader) protocol to get a valid IP address, and TFTP protocol to download an executable (ELF) kernel image combined with the initial RAM disk (inserted as an ELF section) to boot from (the TFTP server's IP address and the image name must be sent by the BOOTP/DHCP server).

To boot the RouterBOARD computer from Ethernet network you need the following:

- An ELF kernel image for the loader to boot from (you can embed the kernel parameters and initrd image as ELF sections called *kernparm* and *initrd* respectively)
- A TFTP server which to download the image from
- A BOOTP/DHCP server (may be installed on the same machine as the TFTP server) to give an IP address, TFTP server address and boot image name

See the RouterBOOT section on how to configure loader to boot from network.

Note that you must connect the RouterBOARD you want to boot, and the BOOTP/DHCP and TFTP servers to the same broadcast domain (i.e., there must not be any routers between them).

## Operating System Support

MikroTik RouterOS starting from version v5. If your device is preinstalled with an earlier RouterOS release, please upgrade RouterOS to v5.6 or newer.

## Software Reset

It is possible to reset all software configuration by using the Software Reset jumper (reset2) during the power-up. No confirmation or passwords will be asked, so use with caution. This feature can be disabled in the “**system routerboard settings**” menu by switching the “**enable-jumper-reset**” parameter to “**no**”.

Simply use a metal object to short circuit the metallic reset jumper while booting.

## RouterBOOT

The RouterBOOT firmware (also referred as Bootloader here) provides the basic functionality to boot an Operating System. It supports serial console via the onboard serial port at the boot time. The loader supports booting from the onboard NAND device and from a network server (see the respective section for details on this protocol).

## Boot Loader Configuration

Loader parameters may be configured through the onboard RS232C DB9 asynchronous serial interface. To connect to it, use a standard null-modem cable. By default, the port is set to 115200bit/s, 8 data bits, 1 stop bit, no parity. **Note** that the device also implements the hardware (RTS/CTS) flow control.

To enter the loader configuration screen, press any key (or only [Delete] key (or [Backspace] key – see the note for the respective configurable option), depending on the actual configuration) just after the boot loader is asking for it:

```
RouterBOOT booter 2.33

RouterBoard 435

CPU frequency: 680 MHz
Memory size: 256 MB

Press any key within 2 seconds to enter setup

RouterBOOT-2.33
What do you want to configure?
  d - boot delay
  k - boot key
  s - serial console
  n - silent boot
  o - boot device
  f - cpu frequency
  r - reset booter configuration
  e - format nand
  g - upgrade firmware
  i - board info
  p - boot protocol
  b - booter options
  t - do memory testing
  x - exit setup
your choice:
```

To select a menu point, press the key written at the beginning of this line. Pressing [Enter] selects the option marked with '\*'.

**boot delay** – how much time to wait for a key stroke while booting (1..9 seconds; **2 second** by default).

**boot key** – which key will cause the loader to enter configuration mode during **boot delay** (any key | <Delete> key only; **any key** by default). Note that in some serial terminal programs, it is impossible to use the [Delete] key to enter the setup – in this case it might be possible to do this with the [Backspace] key.

**serial console** – to configure initial serial console bitrate (1200 | 2400 | 4800 | 9600 | 19200 | 38400 | 57600 | 115200; **115200** bps by default).

**boot device** – initial boot device (boot over Ethernet | boot from NAND, if fail then Ethernet | boot from CompactFlash only | boot Ethernet once, then NAND | boot Ethernet first, then CompactFlash | boot from NAND only; **boot from NAND, if fail then Ethernet** by default). You can also select **boot chosen device** option to boot from the device selected immediately, without saving the setting.

**reset configuration** – whether to reset all the boot loader settings to their respective default values (yes | no; **no** by default).

**format nand** – perform a low-level NAND format. During this operation, all previously marked bad sectors are retested to find out if they are faulty indeed.

**upgrade firmware** – receive a new boot loader image using XModem protocol over serial line or using DHCP/BOOTP and TFTP protocols through the Ethernet network (upgrade firmware over ethernet | upgrade firmware over serial port).

**board info** – prints the serial number, boot loader version, CPU frequency, memory size and MAC addresses of the onboard Ethernet ports

**boot protocol** – network booting protocol (bootp protocol | dhcp protocol; **bootp protocol** by default).

**do memory testing** – performs a full memory test.

**cpu-frequency** –

selects a memory and CPU frequency combination to increase or decrease performance of the device

```
100MHz 150MHz 200MHz 300MHz 400MHz 600MHz 680MHz 800MHz
```

## Boot Loader Upgrading

The boot loader is needed to initialize all the hardware and boot the system up. Newer loader versions might have support for more hardware, so it's generally a good idea to upgrade the loader once a newer version is available.

The boot loader upgrading is possible from MikroTik RouterOS, from within the “/system routerboard” menu. Updates are included with each RouterOS update. The procedure is described in the MikroTik RouterOS manual: [http://wiki.mikrotik.com/wiki/Manual:Bootloader\\_upgrade](http://wiki.mikrotik.com/wiki/Manual:Bootloader_upgrade)

You can also upgrade the loader through the onboard serial port using XModem protocol (programs available for all major OSs). For example, you can use HyperTerminal for Windows or Minicom for Linux to upload the boot loader. Alternatively if you have a DHCP/BOOTP and TFTP servers available, you can specify the loader image as a boot image and choose the **bios upgrade over ethernet** option in the boot loader configuration menu. The loader will get the image from the TFTP server and upgrade itself. The most current loader image is available for download on [www.routerboard.com](http://www.routerboard.com).

## Primary Boot Loader

There are two boot loaders present on the NOR flash memory chip. Secondary is the main one, that is executed by default. This is the one that can be upgraded. In case something goes wrong in the upgrade process, or you have set some incorrect settings that render it unusable, you can load the Primary boot loader by holding the Software Reset 1 button (**S401**), connecting the power, and then releasing the button/jumper. The Primary boot loader has the default settings, which can not be changed. It is also not possible to upgrade it.

## RouterOS functions

The default OS of RouterBOARD devices is RouterOS, when the *routerboard.npk* package is installed, RouterOS can configure some RouterBOARD hardware settings without the need to enter RouterBOOT menu through the serial console.

## Health monitor

This menu shows the fan, current, voltage, consumption and temperature status:

```
/system health> print
fan-mode: auto
use-fan: main
```

```
active-fan: none
  voltage: 23.8V
  current: 198mA
temperature: 23C
power-consumption: 4.7W
```

## Firmware information

This menu displays RouterBOARD model number, serial number, the current boot loader version and the version available in the current software packages installed.

```
[admin@MikroTik] > system routerboard print
routerboard: yes
  model: "rb435"
  serial-number: "154201C1DD3C"
current-firmware: "2.27"
upgrade-firmware: "2.27"
[admin@MikroTik] >
```

The firmware version can be upgraded from **RouterOS** by using **"/system routerboard upgrade"** command.

## Firmware Settings

Boot loader settings are also accessible through this menu.

```
[admin@MikroTik] > system routerboard settings print
  baud-rate: 115200
  boot-delay: 2s
  boot-device: nand-if-fail-then-ethernet
enter-setup-on: any-key
  boot-protocol: bootp
enable-jumper-reset: yes
[admin@MikroTik] >
```

The Software Reset jumper, which resets both boot loader settings and RouterOS settings by default, can be disabled in this menu (it will still reset the boot loader settings).

If you have some device connected to the serial port, and signals from it cause the RouterBOOT to be loaded, you can set „setup key” to be something more specific than „any key”.

# Appendix

## Connector Index

J301	RS232C male DB9 serial port	
	2	RxD (Receive Data)
	3	TxD (Transmit Data)
	5	GND
	7	RTS (Request to Send)
	8	CTS (Clear to Send)
Ether1-3	RJ45 Gigabit Ethernet 1000Base-T ports	
J101	Power Jack (12/24V DC)	

## Button Index

S301	Software Reset 1 button. Loads the Primary boot loader (see "Primary Boot Loader")
Reset2	Software Reset 2 jumper hole. Resets RouterOS settings (see „Software Reset“)

## Gigabit Ethernet RJ45 Connector

RJ45 Pin	Color	Function (100Mbit)	Function (1Gbit)	RJ45 pin for Straight cable (MDI, EIA/TIA568A)	RJ45 pin for Crossover cable (MDI-X, EIA/TIA568B)
1	Green	TX+ Data	Data A+	1	3
2	Green/White	TX- Data	Data A-	2	6
3	Orange	RX+ Data	Data B+	3	1
4	Blue	-	Data C+	4	4
5	Blue/White	-	Data C-	5	5
6	Orange/White	RX- Data	Data B-	6	2
7	Brown	-	Data D+	7	7
8	Brown/White	-	Data D-	8	8

**Note:** When using the MikroTik Gigabit PoE injector, PoE is passed on pins 4,5 (+) and 7,8 (-). When using other PoE injectors, power can be passed on any other pins, depending on PoE injector model.

## Serial Null-modem (Console) Cable with Loopback

DB9f	Function	DB9f	DB25f
1 + 4 + 6	CD + DTR + DSR	N/C	N/C
N/C	CD + DTR + DSR	1 + 4 + 6	6 + 8 + 20
2	RxD	3	2
3	TxD	2	3
5	GND	5	7
7 + 8	RTS + CTS	7 + 8	4 + 5

N/C – not connected.