

## **User Manual and Safety Information**

Please read the following safety notes before use!

### **WARNING**

\*Disconnect from mains supply in case of malfunction or damage and send the unit to the manufacturer or importer for inspection.

\*Dangerous voltages occur on the inside of the unit. The housing must not be opened. The power supply does not contain any serviceable parts.

\*Adhere to the specifications on the nameplate. Check for correct voltage and polarity, as well as the suitability of the power supply for the intended use. Load must not exceed nominal values. Relevant industry standards and accident-prevention regulations for installation, connection and operation must be observed. Ground (FG), if any exists, must be connected to earth ground.

\*For dry indoor environments only. Keep dry and out of direct sunlight, do not cover. Do not operate near heat sources. Unit is not waterproof and not splash-proof.

\*Disconnect from mains power line when not in use

\*Naked flame sources, such as candles, must not be placed on the appliance.

\*The appliance is suitable for moderate climates only

### **Intended Use**

This switching power supply is intended for powering low voltage consuming devices and is in conformance with relevant European Directives. This device is intended to use with Audio/video, information and communication technology Equipment only.

### **Disposal**

The appliance shall not be disposed together with the normal waste. It must be recycled. Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposal at least for free of charge.